



- | | | |
|----------------------------------|-----------------------------------|---------------------------------------|
| 1. Left Frame | 28. Puncture Frame Catch A Spring | 55. Bolt Sear Pin |
| 2. Right Frame | 29. Trigger | 56. Reverse Hold Latch Pin |
| 3. Muzzle Plug | 30. Trigger Pin | 57. Sear Base |
| 4. Muzzle Plug Screw | 31. Trigger Bar A | 58. Sear Base Screw |
| 5. Front Sight | 32. Puncture Frame Catch B | 59. Sear Pin |
| 6. Magazine Follower Spring | 33. Puncture Frame Catch B Spring | 60. Sear |
| 7. Magazine Follower A | 34. Frame Screw | 61. Sear Spring |
| 8. Magazine Follower B | 35. Magazine Cover | 62. Selector |
| 9. Inner Barrel | 36. Mechanism Frame Left | 63. Bolt Spring Guide A |
| 10. Barrel C-ring Clip | 37. Mechanism Frame Right | 64. Bolt Spring Guide B |
| 11. Feed Nozzle Spring | 38. Cocking Lever | 65. Bolt Spring Guide C |
| 12. Feed Nozzle | 39. Cocking Lever Spring | 66. Bolt Spring |
| 13. Valve Body | 40. Sear Bar Spring | 67. Bolt Spring Washer |
| 14. Puncture Pin Retainer O-ring | 41. Sear Bar | 68. Bolt Spring Guide D |
| 15. Puncture Pin Assembly | 42. Reverse hold Latch Spring | 69. Safety Lever |
| 16. Valve O-ring | 43. Control Gear Spring Plunger | 70. Red Dot |
| 17. Valve Washer | 44. Control Gear Spring | 71. Safety Block |
| 18. Valve Spring | 45. Rotation Cam Spring | 72. Safety Block Click Plunger |
| 19. Valve | 46. Trigger Bar B | 73. Safety Block Click Plunger Spring |
| 20. Valve Rear Cap | 47. Rotation Nail | 74. Sear Base Spring |
| 21. Piston Ring | 48. Rotation Nail Spring | 75. Mechanism Frame Screw |
| 22. Cylinder Block | 49. Rotation Cam | 76. Selector Lever |
| 23. Hit Pin | 50. Rotation Cam Screw | 77. Selector Lever Screw |
| 24. Trigger Safety | 51. Control Gear | 78. Puncture Frame Assembly |
| 25. Trigger Safety Spring | 52. Reverse hold Latch | 79. Puncture Frame Front Cover |
| 26. Trigger Spring | 53. Bolt Sear | 80. Puncture Screwdriver |
| 27. Puncture Frame Catch A | 54. Bolt Sear Spring | |